

## **Packaging**

### **Roofing Bolts & Nuts**

In cardboard boxes without wasted space inside. Square nuts should be bagged inside box. Box to be sealed with tape. Labeled with size, description and quantity. (Box should be strong enough not to split when dropped from 1.5Metres.)

Outer cardboard cartons not to exceed 25KG in weight. (Boxes must be packed tight inside to ensure no movement during shipping) Labeled with size, description and quantity

Palletized on strong wooden pallets which can be lifted by a hydraulic hand truck as well as a fork lift. with wooden side re-enforcement.

### **Full Nuts**

In plastic bags no less than 600 GAUGE (150 mic). Bag needs to be heat sealed. Labeled with size, description and quantity. (Bag should be strong enough not to split when dropped from 1.5Metres.)

Outer cardboard carton quantities. (Bags must be packed tight inside to ensure no movement during shipping) Labeled with size, description and quantity

M6	10000
M8	5000
M10	2500
M12	1500
M16	1000

Palletized on strong wooden pallets which can be lifted by a hydraulic hand truck as well as a fork lift.

### **HT Setscrews**

In cardboard boxes without wasted space inside. Box to be sealed with tape. Labeled with size, description and quantity. (Box should be strong enough not to split when dropped from 1.5Metres.)

Outer cardboard cartons not to exceed 20KG in weight. (Boxes must be packed tight inside to ensure no movement during shipping) Labeled with size, description and quantity

Palletized on strong wooden pallets which can be lifted by a hydraulic hand truck as well as a fork lift.